

Traitements superficiels S3P de dernière génération pour les aciers et alliages inoxydables

Bodycote S³P, Dr. Andreas Karl, Jean-Christophe Guerin



SURF - THERM

« Nouveautés techniques en micromécanique horlogère et leurs caractérisations » 17 novembre 2016



Typically used for ...




- Medical industry
- Food and beverages processing
- Pumps and valves
- Fastening solutions
- Automotive industry
- Consumer products
- Chemical Industry
- Oil & gas Industry



Different, but not visually





The optical appearance of stainless steel is still metallic blank, but the mechanical properties are massively improved by S³P

Standard processes do not apply




Conventional hardening processes like carburizing, nitriding or nitrocarburizing deteriorate the corrosion resistance.

High temperatures lead to precipitation of chromium nitrides and carbides .




S-Phase Expanded austenite without precipitations



Nitrides and Carbides on the surface followed by a diffusion zone

S³P offers the solution





- Supersaturation of Carbon/Nitrogen
- Gradual hardness increase
- Low temperature diffusion process
- Proprietary process
- Outstanding mechanical properties

Achieving mechanical durability











untreated	Resistance to	S ³ P-treated
+	Corrosion	+
_	Wear	4
_	Galling	4
_	Fatigue	4
_	Cavitation	4

Galling - Fretting



One of the major problems of stainless steel





Laboratoire de Tribologie et Dynamique des Systèmes de l'Ecole Centrale de Lyon

Galling - Fretting



Without surface treatment







Time to failure: AISI 316L - untreated

Time to failure: AISI 316L – S³P K33

~ 1.5 s








Galling - Fretting



- Galling test according to ASTM G98
- Stainless steel AISI 316L
- Unlubricated
- Ground surface finish
- Galling threshold stress rises from 6 KSI to 120 KSI





Abrasive Wear Resistance




Taber Abraser 5131

• Force: 500gf/wheel

500 Cycles

Material: 316L (1.4404)











Wear resistance: Ball on disk




Loading: 10 N

Rotation: 100 rpm at speed 50 mm/s

Ball material: Al₂O₃ (Radius 5 mm)


Wear depth measured after 500 m



Wear depth	untreated	S³P
AISI 420 (1.4034)	15 μm	7 μm
Inconel 625 (2.4856)	82 µm	3 µm

Excellent corrosion resistance maintained









High Strength of S-Phase



- S-Phase has higher strength than base material
 - Geometrical fraction of S-Phase is typically marginal
 - Thus the influence of S-Phase on mechanical strength of a part is typically marginal
 - High strength of S-Phase can be shown on thin walled parts (e.g. thin sheet or foils)









S³P Specialty Stainless Steel Processes


Example: Stainless Steel Springs



- Improved stress corrosion resistance
- Increased fatigue strength
- Higher spring factor (esp. for small springs)









Biocompatibility



- Major medical companies work together with S³P (e.g. implants, medical tools, ...)
- Both stainless steel and CoCrMo-alloys remain biocompatible




hFOB 1.14 human foetal osteoblast cell line




Surface roughness and morphology




Examples	Ra value before S³P in μm	Ra value after S³P in μm
lapped surface	0.04 - 0.05	0.06 - 0.08
machined surface	0.22 - 0.25	0.21 – 0.26





Ra value: ± 0,04 µm



AISI316L + polished + S³P

Ra value: ± 0,08 µm

Optical appearance







- Geometry of finished parts is not changed
- Tight tolerances possible
- Metallic blank stainless steel surface



High Ductility of Carbon S-Phase




Hammer and Nail test – Rapid loading


Material: 316L

Etchant: Beraha II

Left: Bodycote S³P, Carbon S-Phase

Right: Competitor, Nitrogen+Carbon S-Phase







High Ductility of Carbon S-Phase



- Hammer and Nail test
- Rapid loading
- 316L
- S³P
- very ductile Carbon S-Phase

- Bending
- Slow loading (bending)
- 316L
- Electroless Nickel
- Brittle behavior with cracks







S³P as support for hard coatings



- S³P provides a corrosion resistant and ductile diffusion zone with surface hardness around 1000HV microhardness
- Hard coatings (PVD, DLC) are brittle and provide a surface hardness between 2000 and 4500HV
- Egg-shell effect is common risk for hard coatings
- S³P acts as a support structure reducing the risk of egg-shell effect






HV0.05 indentations at 1000x magnification; left: DLC; right: S³P + DLC


Example: High pressure applications






New design is possible: Slide Bearing









- Dosing pumps for food and pharmaceuticals
- Piston/ bearing for automotive industry

Even smallest spacing is treated









Jigging, Fixtures






- Treatment of bulk material is no problem (point and line contacts allowed)
- Highly sensitive surfaces: use of special fixtures by S³P
- Large and heavy components up to Ø1.2 x 2m and 4t

Influences on Corrosion Resistance






Influence of Surface Finish




Example of surface defect on 304 SS formed by grinding, showing local deep grooving




Watch Band Closure



Engraving before hardening



ball-blasting after hardening











USA Bodycote Thermal Processing Inc. 443 E. High Street Ohio, 43140 London

Netherlands
Bodycote Hardingscentrum B.V.
Paramariboweg 45
7333PA Apeldoorn

France
Bodycote Hardingscentrum B.V.
ZAC de Brequette
1, rue des Charpentiers
57175 Gandrange

Sweden
Bodycote Värmebehandling AB
Industriegatan 1
23532 Vellinge

Max-Planck-Straße 38

Germany

61184 Karben

Germany
Bodycote Specialist Technologies GmbH
Max-Planck-Strasse 9
86899 Landsberg

Bodycote Specialist Technologies GmbH